## Aluminum Nitride MEMS FBAR with Integrated Microfluidic Channel

Jeremy Schroeder<sup>1</sup>, Wencheng Xu<sup>2</sup>, Junseok Chae<sup>2</sup>, and Tim Sands<sup>1</sup>

<sup>1</sup>Birck Nanotechnology Center, Purdue University; <sup>2</sup>Electrical Engineering, Arizona State University





## **Objective**

Microelectromechanical system (MEMS) film bulk acoustic resonators (FBAR) operating in a liquid environment will be a useful tool for biological/biochemical screening and diagnosis applications. Such applications use molecular probes that capture target molecules, which are subsequently detected by mass-induced FBAR resonant frequency shifts. FBARs operating in air/vacuum environments trap acoustic waves within the device, thereby achieving high Q and highly sensitive mass detection. Operating FBARs in liquid environments drastically reduces Q by a factor of more than 100, due to acoustic energy dissipation in the liquid. This work aims to overcome the limitations imposed by the liquid environment by integrating a microfluidic channel directly on a MEMS L-FBAR, thereby achieving high Q and improving liquid environment detection limits. If successful, portable analyzers could be fabricated from arrays of AIN-based MEMS FBARs using parallel biomolecular detection of target molecules.

## **Aluminum Nitride**

High quality aluminum nitride (AIN) will be used as the piezoelectric material due to its proven CMOS compatibility, which allows truly chip-scale biochemical detectors to be fabricated. AIN can readily be reactively sputtered from an aluminum target in a nitrogen ambient. The piezoelectric properties of uniaxially-textured polycrystalline AIN approach that of single-crystal AIN provided the full-width-at-half-maximum (FWHM) of the x-ray rocking curve is less than a few degrees. The rocking curve FWHM is mainly governed by the initial surface roughness of the substrate.

## Longitudinal-mode FBAR






Figure 1. Cross-section of longitudinal-mode FBAR with integrated parylene microchannel (Xu et al., IEEE Electr Device L, Vol. 30, No. 6, 2009).




Compared to contour-mode FBARs, longitudinal-mode FBARs with integrated microchannels offer the advantage of increased sensitivity, continuous flow, and real time reaction monitoring, distinct advantages for biological and chemical analysis.

**Figure 2.** Impedance spectrum for a typical C-FBAR using commercially sputtered AIN thin film (Tegal Corp). Q values in air and water were 317 and 189, respectively (Xu, Choi, and Chae, Appl Phys Lett, **96**, 2010).



**Figure 3.** Cross-section FESEM image of as-is deposited AIN/ZrN/AIN stack prior to FBAR processing.



**Figure 4.** XRD rocking curve scan of 002-AIN. 900°C substrate temperature produces high quality AIN.



This work is supported by the NSF/ENG, 0742547, "Collaborative Research: TIE: AIN High-Q MEMS FBAR (Film Bulk Acoustic Resonator) in a Liquid environment"