

Discrete-Time Fourier Transform (DTFT)

Chap 5

- Def'n of DTFT comes from passing DT sinewave thru a DT LTI system

$$e^{j\omega_0 n} \xrightarrow{\boxed{\text{LTI}} h[n]} y[n] = e^{j\omega_0 n} * h[n] = H(\omega_0) e^{j\omega_0 n}$$

Since:

$$\begin{aligned} y[n] &= x[n] * h[n] = \sum_{k=-\infty}^{\infty} h[k] x[n-k] \\ &= \sum_{k=-\infty}^{\infty} h[k] e^{j\omega_0(n-k)} = \left[\sum_{k=-\infty}^{\infty} h[k] e^{-jk\omega_0} \right] e^{j\omega_0 n} \end{aligned}$$

$$\text{DTFT: } H(\omega) = \sum_{n=-\infty}^{\infty} h[n] e^{-j\omega n}$$

Since k is just a dummy variable for summation

- DTFT defined same way for DT signal:

$$X(\omega) = \sum_{n=-\infty}^{\infty} x[n] e^{-j\omega n}$$

- On the next 2 pages, we prove:

If $x[n] = x_a(nT_s)$, n integer, and

$$x_a(t) \xleftrightarrow{\widehat{F}} X_a(\omega) \quad x[n] \xleftrightarrow{\text{DTFT}} X(\omega)$$

then $X(\omega)$ is related to $X_a(\omega)$ as:

$$X(\omega) = X_s(F_s \omega)$$

where: $X_s(\omega) = F_s \sum_{k=-\infty}^{\infty} X_a(\omega - k2\pi F_s)$

- $F_s = \frac{1}{T} = \text{Sampling rate} = \text{no. of samples / second per}$

(3)

• To derive this relationship, recall that

for "sampled" signal, we have:

$$x_s(t) = x_a(t) \left(\sum_{n=-\infty}^{\infty} \delta(t - nT_s) \right) = \sum_{n=-\infty}^{\infty} x_a(t) \delta(t - nT_s)$$

$$= \sum_{n=-\infty}^{\infty} x_a(nT_s) \delta(t - nT_s) = \sum_{n=-\infty}^{\infty} x[n] \delta(t - nT_s)$$

• Taking the CT Fourier Transform:

$$X_s(\omega) = \sum_{n=-\infty}^{\infty} x[n] e^{-j\omega n T_s} = \sum_{n=-\infty}^{\infty} x[n] e^{-j\left(\frac{\omega}{F_s}\right)n}$$

• Comparing with formula for DTFT obtained from passing DT sine wave thru DT LTI System

$$X(\omega) = \sum_{n=-\infty}^{\infty} x[n] e^{-j\omega n}, \text{ we have } X(\omega) = X_s(F_s \omega)$$

- In our previous derivation for Sampling Theory for Chap. 7, rather than bring $x_a(t)$ inside the sum and taking the STFT, we invoked the time-domain product property of the FT:

$$x_s(t) = x_a(t) \left(\sum_n \delta(t - nT_s) \right) \xleftrightarrow{\mathcal{F}}_{2\pi} \frac{1}{2\pi} X_a(\omega) * \frac{1}{T_s} \sum_k \delta(\omega - k\frac{2\pi}{T_s})$$

$$= X_s(\omega) = F_s \sum_{k=-\infty}^{\infty} X_a(\omega - k2\pi F_s)$$

- This completes proof:

$$X(\omega) = X_s(F_s \omega)$$

where: $X_s(\omega) = F_s \sum_{k=-\infty}^{\infty} X_a(\omega - k2\pi F_s)$

$$X(\omega) = F_s \sum_{k=-\infty}^{\infty} X_a(F_s \omega - k2\pi F_s) = \sum_{k=-\infty}^{\infty} X_a(F_s(\omega - k2\pi))$$

(5)

- Recall fundamental principle:

Sample in time domain \longleftrightarrow replications in the frequency domain periodically spaced every integer multiple of $\omega_s = 2\pi F_s$

- The compression by F_s causes the replications in the DTFT to occur at every integer multiple of $\frac{\omega_s}{F_s} = 2\pi$

- Thus, a DTFT is periodic with period 2π

- This can be seen mathematically since

$$X(\omega + l 2\pi) = \sum_{n=-\infty}^{\infty} x[n] e^{-j(\omega + l 2\pi)n}$$

$$\text{integer} = \left\{ \sum_n x[n] e^{-j\omega n} \right\} \underbrace{\left(e^{-j 2\pi} \right)^l}_{} = 1$$

- To further drive home the point, consider sampling

a sinewave: $x_a(t) = e^{j\omega_a t}$

subscript "a"
is analog

$$x[n] = x_a(nT_s) = x_a\left(\frac{n}{F_s}\right) = e^{j\omega_a \frac{n}{F_s}} = e^{j\frac{\omega_a}{F_s} n}$$

- The frequency of the resulting DT sinewave is:

$$\boxed{\omega_d = \frac{\omega_a}{F_s}} \Rightarrow \text{division by the sampling rate} \Rightarrow \text{compression by the sampling rate}$$

- The DT frequency variable may be viewed as a normalized frequency variable
 \Rightarrow normalized by the sampling rate $F_s = \frac{1}{T_s}$

- That is, regardless of the sampling rate, the DTFT is periodic with period 2π
 \Rightarrow the replications occur every integer multiple of 2π

7

- examine relationship between DT frequency variable and analog frequency variable w_a

$$\boxed{w = \frac{w_a}{F_s}}$$

- If you sample at a rate $w_s = 2\pi F_s$, the highest frequency you can "see" is $\frac{w_s}{2} = \pi \frac{F_s}{2} = \pi F_s$

analog

- This highest frequency is mapped to the DT

frequency: $\frac{\pi F_s}{F_s} = \pi$

- That's why π is the highest DT frequency!!

- recall: any DT frequency outside the range $-\pi < w < \pi \Rightarrow$ you can subtract (or add) an integer multiple of 2π to put in $-\pi < w < \pi$

Sampling an Analog Sinewave

$$x_a(t) = e^{j\omega_a t} \quad \omega_a: \text{analog frequency in radians/sec}$$

$$F_s = \frac{1}{T_s} = \text{no. of samples/sec} \Rightarrow \text{Sampling rate in Hz}$$

$$\begin{aligned} x[n] &= x_a(nT_s) = x_a\left(\frac{n}{F_s}\right) \\ &= e^{j\omega_a n T_s} = e^{j\omega_d n} \end{aligned}$$

where: $\omega_d = \frac{\omega_a}{F_s} = \omega_a T_s$

discrete-time frequency

Key relationship between DT frequency and CT frequency:

$$\boxed{\omega_d = \frac{\omega_a}{F_s}}$$

- Consider: $(\omega_a + l 2\pi F_s) t$

$$x_{a_k}(t) = e^{j \cdot (\omega_a + l 2\pi F_s) t}$$

l , integer

$$x_k[n] = x_a(n T_s) = x_a\left(\frac{n}{F_s}\right)$$

$$w_s = 2\pi F_s$$

Sampling
rate in
rads/sample

$$= e^{j \omega_a n T_s} e^{j l 2\pi F_s n T_s}$$

$$= e^{j \omega_d n} e^{j l n 2\pi}$$

$$\omega_d = \frac{\omega_a}{F_s}$$

$$= e^{j \omega_d n}$$

- any two analog frequencies separated by $l \omega_s$

get mapped to same DT sinewave

- Since $\omega_d = \frac{\omega_a}{F_s} \Rightarrow$ any 2 CT sinewaves separated by $l \omega_s$
 \Rightarrow yields 2 DT sinewaves separated by $l 2\pi$
 \Rightarrow same DT sinewave


(8)

Example : $x_a(t) = \frac{2\pi}{W} \left\{ \frac{\sin(\frac{\omega}{2}t)}{\pi t} \right\}^2$

- sampled at a rate $\omega_s > 2\omega_{max}$


where $\omega_{max} = W$

$$x_a(t) = \frac{2\pi}{W} \left\{ \frac{\sin(\frac{\omega}{2}t)}{\pi t} \right\}^2 \leftrightarrow \tilde{x}_a(t)$$




For sampled signal:

$$\tilde{x}_s(t) \leftrightarrow \dots$$



Compress/
Divide by
Sampling
rate $F_s = \frac{1}{T}$



(9)


$$\text{Note: } x[n] = x_a(nT_s) = \frac{2\pi}{W} \left\{ \frac{\sin(\frac{\omega_c}{2}nT_s)}{\pi n T_s} \right\}^2$$

$$= \frac{2\pi}{W} \left\{ \frac{\sin(\frac{\omega_c}{2F_s}n)}{\pi n/F_s} \right\}^2 = \frac{2\pi F_s^2}{W} \left\{ \frac{\sin(\frac{\omega_c}{2}n)}{\pi n} \right\}^2$$

where: $\omega_c = \frac{W}{F_s}$

now divide by $F_s \Rightarrow$ divide by F_s in freq. domain
and we got our first DTFT pair:

$$\frac{2\pi}{\omega_c} \left\{ \frac{\sin(\frac{\omega_c}{2}n)}{\pi n} \right\}^2 \xleftrightarrow{\text{DTFT}} \dots$$



See "CTFT-DTFT" Relationship for a Sampled Sinewave
for DT Sinewave:

$$x[n] = e^{j\omega_0 n} \xleftrightarrow{\text{DTFT}} \dots$$

